



Stop End (E65) This design conforms with Plumbing Code AS3500 page 41, table 4.6 note. Shower outlets may be used as floor waste gullies.

The loose fitting Spigot provides an outlet for moisture in the waterproof rebate and allows the Channel to be removed for safe keeping until tiling.

The F40 Spigot fits in a 50DWV pipe and should drain 1 L/s

One bathroom tap delivers 0.5 L/s. approx.

Drill 51mm hole and glue Spigot to bottom of Channel with clear PVC solvent cement.

Install the P.trap & fittings as per the Plumbing Code of Australia AS3500.

