



This design conforms with Plumbing Code AS/NZS 3500. The loose fitting spigot provides an outlet for moisture in the waterproof rebate and allows the Channel to be removed for safe keeping until tiling.

The F100 spigot should drain over 1 litre per second. A bathroom tap delivers 0.3 l/s approx.

**STORMTECH
100AG**

Drill 89mm hole and glue Spigot to bottom of Channel with clear PVC solvent cement.
Fix stop ends (E100's) with same glue.
When cutting grate, use a 32 tooth per inch hacksaw, & cut by hand. DO NOT use a grinder, cutoff saw etc.

Install the P.trap & fittings as per the Plumbing Code of Australia AS3500.